

### Step 1

Cut track to required length, allowing enough for an overlap at each end, if required

### Step 2

Slide end caps into end of track and lock with self-tapping screw (see Fig. 1).

### Step 3

Brackets can be fitted either to the ceiling by screwing directly up through the top of the bracket or by face fixing by using the key hole slot at the back.

### Step 4

Allow 30cm between each bracket, with the end brackets approx. 25cm from each end (See Fig. 2)

Attach track to brackets, top edge first, then apply pressure to bottom edge – track will snap into place (see Fig. 3).

When track has been snapped into all brackets, slide track into required position. Push all levers into locking position to secure the track (see Fig. 4).

### Step 5

Fit glider hooks into curtain heading tape, spacing out approx. every 10 cm, then snap onto track by hooking over top edge of track first and then snapping over the bottom edge (see Fig. 5).

Secure the ends of the curtain by fitting the end pockets onto the end stop (see Fig. 6).

Curtain hooks can be used and inserted into the gliders where curtains are to hang beneath the track.

### Please Note:

There is a facility to hang your curtains around the side of the track by fitting an extra glider into the required position (see Fig. 7).

Fig. 1




Fig. 2



Fig. 3



Fig. 4




Fig. 5




Fig. 6

Fig. 7

